

DONNING INSTRUCTIONS

#570 Ms. MILLER HARNESS

The Ms. Miller harness contains a waist strap that is adjustable with a friction style buckle configuration. Since the waist strap does not completely unbuckle, steps 2, 3, and 5 from the Miller harness instruction booklet must be altered as follows:

2. If leg straps are buckled, release straps and unbuckle at this time.

3. Holding harness by the shoulder straps, step through the waist strap and slip the shoulder straps over the shoulders so the d-ring is located in the middle of the back between the shoulder blades.

5. Tighten waist strap. The waist strap should be tight, but not binding.

QUESTIONS?? CALL
1-800-873-5242

I152 Rev. B

MILLER[®]
by SPERIAN

